ROOTLAB

VOGUE

Tower Shelving Unit

Assembly and user instructions



MODELS

L927 / L928 / L929 / L939 / U256 / U257 / U258 / U259 / U276 / U884

Supplied in Australia by **Rootlab Technologies Pty Ltd**

Safety instructions

- **DO NOT** stand or climb on the shelving unit.
- **DO NOT** drop heavy items on the shelving unit.
- **DO NOT** place heavier items on the top of the shelving unit than on the bottom.
- **DO NOT** move the shelving unit when loaded.
- While all care has been taken to remove sharp edges, take care when cleaning or handling the shelving unit to prevent injury from exposed metal edges.

Pack contents

ⓘ **Check all packaging materials for any small parts that may have come loose during transport.**

x4 Lower pole section	**x4** Upper pole section
x16 Shelf sleeve U276: x20	**x4** Shelf U276: x5
x1 Instruction manual	Castors for the U884 are sold separately. Contact Rootlab to order.

Cleaning, care and maintenance

- Clean the shelving unit using warm soapy water.
- Dry thoroughly after cleaning.

Assembly

Part 1: Join the poles and fit the bottom shelf




Fig. 1




Fig. 2

1. Screw the upper poles to the lower poles. Make sure the poles are securely screwed together.

> ⓘ **The upper poles have black plastic caps at one end and a thread at the other.**

2. Select the required height for the bottom shelf. Shelves can be attached at any of the circular grooves, spaced 25 mm apart along the pole.
3. Attach the sleeve to the pole at the required position **(Fig. 1)**.

> ⓘ **The bottom shelf should never be more than 300 mm from the floor. Shelves should never be more than 450 mm apart.**

4. Holding the shelf on its side, slide the pole through one of the corner holes **(Fig. 2)**.

Assembly

Part 2: Add the remaining shelves and level the unit




Fig. 3




Fig. 4

5. Once all four poles are through the corner holes, stand the shelving unit upright and press the bottom shelf firmly onto the sleeves **(Fig. 3)**.
6. Locate the next shelf by counting grooves on the pole to the desired height. Attach a pole sleeve and repeat for each pole **(Fig. 4)**.
7. Lift the shelf up and onto the four poles, sliding the shelf down onto the sleeves.
8. Repeat steps 6 and 7 for each remaining shelf.
9. If necessary, adjust the feet on the bottom of each pole to level the shelving unit.

25 mm	**300 mm**	**450 mm**
between grooves on each pole	max height of bottom shelf	max gap between shelves

ROOTLAB

Supplied in Australia by Rootlab Technologies Pty Ltd

ABN	52 682 799 711
ADDRESS	Unit 14, 49 Carrington Road Marrickville NSW 2204
PHONE	1300 386 487 (1300 FUNGUS)
EMAIL	info@rootlab.com.au
WEBSITE	www.rootlab.com.au

Need a hand?

For help with assembly, missing parts or replacement components, contact Rootlab with your model number and order number.

Every effort is made to ensure all details are correct at the time of printing. However, specifications may change without notice.